

1 Power Kit Installation




Yobi

The power kit must be wired to your internal doorbell.


Meet Yobi B3, a smart video doorbell specifically engineered with you and your family's safety in mind. With Yobi B3, you'll always know who's knocking or walking up to your front door. Anywhere, anytime.



Overview Schematic




How to Install Your Power Kit




Step 1 Locate your internal doorbell and remove the cover

For your safety, please shut off your home's electrical power supply before you begin the installation.



Step 2 Unplug the wires from your doorbell


Locate the two wires on your doorbell, then loosen the screws and unplug them.



Step 3 Plug the wires into the cable connectors


a) With your finger, apply light pressure to lift the orange lever.

b) Insert the wires and snap the lever down.




Step 4 Attach the cable harness

Insert the brown end of the black cable harness, and the blue end of the white cable harness into the doorbell. Then secure them in place with the original screws.



Step 5 Secure the power kit and cable connectors


Find a safe location for your power kit and cable connectors without them interfering with any other parts of your doorbell.



* If necessary, use the provided adhesive on the back of the power kit and cable connectors.


Step 6 Return the doorbell cover to its original position

You're now ready to install your Yobi B3 to the front of your home. To do so, please follow the steps in the next manual.



2

Install Your Doorbell Yobi B3



Yobi

Product Overview

Security Slot

Security Screw Slot

PIR Array

Light Sensor

MIC

IR Light

Reset Button

5V Power In (Optional)

Terminals (Attach existing wiring here)


Security Slot


1 Support


2 Auxiliary Supports (left-right/up-down direction)


If you need to adjust the direction of your Yobi B3, you can choose one of the two auxiliary supports.


Tool Box Components


 1 Screwdriver- Use to mount the screws.


 1 Drill Bit- Use to drill holes when using the anchors.


 6 Anchors- Use to install on different surfaces like stucco, concrete, or brick.

 6 Mounting Screws (long)- Use to position the support or the auxiliary support onto the wall.

 6 Mounting Screws (short)- Use to position the auxiliary support onto the wall.

 2 Security Screws- Use to secure Yobi B3.


 2 Extra Wires- Use to connect the AC wires and the terminals on the back of Yobi B3.

 2 Wire Nuts- Use to connect extra wires and AC wires.

Step 1

Remove your existing doorbell


Before you begin, make sure your home's electrical power is shut off. Then remove the existing doorbell and disconnect the wires.



Step 2

Installing anchors on different surfaces (Optional)

When installing on a different surface like stucco, brick, or concrete, use the provided drill bit to drill holes and insert the anchors.




* If you're installing on wood, skip this step and save the anchors for future use.

Step 3

Install the support on the wall

Use the provided screwdriver to position the support onto your wall with the 4 long mounting screws.




Step 4

Install the auxiliary support before the support if needed (Optional)

1. Use 2 long mounting screws to place the auxiliary support on the wall.


2. Use 4 short mounting screws to place the support on the auxiliary support.



Step 5

Connecting the wires

Screw your Yobi B3 to the connection wires on your wall. Once it's connected to electricity, you will hear the doorbell ring.




* If the wires aren't long enough to screw, use the extra wires and wire nuts provided.

Step 6

Security Screw

Secure Your Yobi B3 on the top with the security screw provided.




Step 7

Reset the Yobi B3 (Optional)

Remove your doorbell Yobi B3 from the wall.

- Loosen the security screw on the top of the doorbell with the screwdriver provided.


- Pull out the doorbell with your hand from the security slot.



Step 8

Press the Reset Button (Optional)


To reset your doorbell Yobi B3, press the reset button for five seconds until you hear "Reset successful."




3

Perform the in-app setup


Features




Full HD 1080p




Live View




Two-Way Talk




Smart PIR Motion Sensors




Facial Backlight Compensation (Patent Pending)



Weather-Resistant and Waterproof



180° Field of View



Night Vision

Step 1 Open the Home app

Can't find it? Download it from the App Store.

Use of the Works with Apple HomeKit logo means that an electronic accessory has been designed to connect specifically to iPod touch, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.








Step2 Connect Yobi B3

Before installing on the Home App, make sure your doorbell is powered on.

- Go to Settings-> Wi-Fi-> Set Up New Device.
- Tap on the device number, then wait for your device to join your Wi-Fi.
(Only compatible with 2.4GHz networks.)
- Open the Home app.
- Tap on “Add Accessory” and follow the on-screen instructions to set up and configure your doorbell.
(The QR code is on the back of your doorbell.)


* If the installation is not successful, please check if the router firewall is closed.

The LED light indicator on the front of your Video Doorbell Yobi B3 indicates your camera's status. You can determine the status by matching the color patterns below:

Camera is Powered on		Solid Blue
Camera is Setting up		Loading Red
Wait for Installation		Spinning Red
Installing		Loading Blue
Successfully Installed		Solid Blue
Doorbell is Ringing		Spinning Blue/Red
No Internet Connection		Flashing Red

When someone rings your Yobi B3, your phone will receive a push notification within 1 second. Tap the notification to view the video feed.

* When motion is detected, the motion sensors are triggered.

<div data-bbox="181 807 410 834">Upgrade Firmware</div> <div data-bbox="181 851 748 906"> If you need to upgrade your Yobi B3 firmware, please download the Yobi Home App from the App store. </div> <div data-bbox="308 970 600 1055">  </div> <div data-bbox="181 1110 367 1136">Remote Access</div> <div data-bbox="181 1154 756 1283"> Controlling this HomeKit-enabled accessory automatically and away from home requires a HomePod, an Apple TV with tvOS 10.3 or later, or an iPad with iOS 10.3 or later set up as a home hub. </div>	<div data-bbox="824 802 896 829">Q & A</div> <div data-bbox="824 854 1399 1406"> <p>Q1: What doorbell transformers are compatible with Yobi B3 doorbell? A1: You can connect Yobi doorbell to transformers operating between 8V and 24V AC.</p> <p>Q2: Does B3 doorbell operate on battery power? A2: No. Since Yobi B3 will be installed using your home's original doorbell, it will be connected to your home's electricity.</p> <p>Q3: Do I have to turn off the power in my house before installing Yobi B3? A3: Yes! Since your current doorbell will be connected to your home's electricity, we recommend you shut off the power to avoid any potential risks during the installation of your Yobi B3.</p> <p>Q4: Will I have to purchase anything at a hardware store to install my B3 device? A4: No. Everything you need to install your Yobi B3 doorbell (tools, screws & wires) is included in the package.</p> </div>	<div data-bbox="1488 854 2071 1381"> <p>Q5: Do I need a Wi-Fi connection to set up my B3 device? A5: Yes. You will need a Wi-Fi connection with a 2.4GHz band to install and use all the features of your doorbell.</p> <p>Q6: If I am on my smartphone without any Wi-Fi connection, will I still be able to see my visitors? A6: Yes, you can still view your doorbell's video feed as long as you have LTE mobile data and a hub set up in your home.</p> <p>Q7: Is Yobi B3 compatible with Android devices? A7: No. Yobi B3 is a HomeKit enabled device that works only with iOS products like iPhone, iPad, Apple TV, and HomePod.</p> <p>Q8: Which iOS devices can be used as a hub? A8: You can use an iPad, Apple TV, and HomePod as a hub.</p> <p>Q9: Does Yobi B3 work with other home automation devices? A9: No. B3 only works with Apple HomeKit.</p> </div>	<div data-bbox="2156 854 2739 1362"> <p>Q10: Does B3 device use Bluetooth? A10: No. Yobi B3 works with your home Wi-Fi.</p> <p>Q11: Can multiple users use Yobi B3? A11: Yes! You can give access to family members and guests after you set up your hub.</p> <p>Q12: Will all users associated with my B3 device be notified when there's a notification? A12: Yes. All users will be notified whenever Yobi B3 sends a notification. Invited users will also be able to interact with visitors using the two-way talk.</p> <p>Q13: Does B3 provide a live video feed? A13: Yes. B3 is equipped with live view, which allows users to stream live video.</p> <p>Q14: Can I record and store the videos from the camera? A14: No. You can't record or store videos from the doorbell.</p> </div>	<div data-bbox="2820 851 3395 1356"> <p>Q15: Why is the video feed not loading? A15: This can sometimes happen when there's a poor connection between your Yobi B3 device and your router. We recommend using a router extender next to your front door to increase the range of your Wi-Fi network. After you do this, force quit the Home App and then relaunch it.</p> <p>Q16: What is the video quality put out by B3 devices? A16: Full HD 1080p video.</p> <p>Q17: Can Yobi B3 withstand the elements: extreme heat, cold, rain, and snow? A17: Absolutely. Yobi B3 is made from waterproof and weather-resistant materials that can withstand extreme weather.</p> <p>Q18: Is B3 video doorbell FCC approved? A18: Yes. Yobi B3 is FCC approved.</p> </div>	<div data-bbox="3492 813 3826 839">Return and Exchange Policy</div> <div data-bbox="3492 857 4071 1098"> Yobi has a 30-day return and exchange policy and a one-year warranty (excluding man-made damage). Please contact customer support for more information on returns and exchanges. When returning, make sure the product is in its original packaging, undamaged and complete with all accessories. Customers will need to pay shipping when returning Yobi B3 based on non-quality problems. </div> <div data-bbox="3492 1144 3767 1170">Yobi Technical Support</div> <div data-bbox="3492 1188 3999 1243"> If you encounter any problems, don't hesitate to contact us! </div> <div data-bbox="3492 1280 3822 1307"> Email: Support@MeetYobi.com </div>
--	---	---	--	--	--